Astro-Cooler® SideGuard Installation, Removal & Storage

6'x 110' Thermal Reflective Side Guard 12 Rolls per pallet

For further information contact: 916-381-3325

For full video instructions go to: http://astrocooler.com/video.html






Astro-SideGuard Installation

SideGuard is used in conjunction with an Astro-Cooler® Blanket or the Astro-Quilt®. It protects goods from damage due to conduction of heat or cold through the side walls of a container. SideGuard is 6' x 110' (you trim any excess length). Taller sizes can be produced for those shippers stacking pallets higher. View Installation Video HERE.

Install using standard or double sided tape to attach the SideGuard to the container wall:

A third snap-on option utilizing magnates is also available (not shown here)

1. Standard Tape: unroll the SideGuard as you move along the side walls of the container and attach tape every few feet as needed. Make sure that the foil side is facing in towards the load.





2. Double sided tape: First, apply tape to container walls. Second, peel off tape backing. Lastly, unroll SideGuard against the wall (Foil Facing In).







Once you finish installing the SideGuard, normal loading of the container can begin.



